



GROUND SAFETY RECOMMENDATION

UTILIZZO SCALE ESTERNE LOADING BRIDGE

L'accesso alle scale esterne dei loading bridge è **tassativamente vietato al personale non autorizzato**, l'accesso è da ritenersi ad uso esclusivo delle operazioni di rampa (incluso walk around/pre-flight inspection).

Durante il loro utilizzo, al fine di evitare potenziali cadute, occorre:

- verificare preventivamente che siano prive di materiale sdruciolevole (in caso si rilevasse tale problematica contattare immediatamente la Control Room di Manutenzione SEA e non utilizzare la scala),
- utilizzare calzature consone e prive di tacchi,
- percorrere un gradino alla volta mantenendosi sempre al corrimano,
- non utilizzare la scala per trasportare materiale (in caso di necessità utilizzare la scala interna della torretta del satellite).

Porre sempre la massima attenzione poiché la scala, a seguito della tipologia di aeromobile servito dal loading bridge, presenta una inclinazione variabile.

Per tutte le altre necessità di accesso al piazzale aeromobili si **DEVONO SEMPRE** utilizzare le scale di servizio interne alle torrette dei satelliti.



Be safe at all times!

Assicurarsi che questa Ground Safety Recommendation sia ben visibile nel vostro luogo di lavoro (Safety Corner)



GROUND SAFETY RECOMMENDATION

LOADING BRIDGE EXTERNAL STAIRS UTILISATION

Access to the external stairs of the loading bridges **is strictly forbidden for unauthorized personnel**, access is to be considered for the exclusive use of ramp operations (including walk around / pre-flight inspection).

During their utilisation, in order to avoid potential falls, it is necessary to:

- check in advance that they are free of slippery material (if this problem arises, contact the SEA Maintenance control room immediately and do not use the stair),
- use suitable footwear without heels,
- walk one step at a time and always hold on to the handrail,
- do not use the stair to transport material (if necessary, use the internal stair of the satellite structure).

Always pay attention that stair inclination may vary, due to the type of aircraft served by the loading bridge.

For all other access needs to the airport apron, the service stairs inside the satellite turrets **MUST ALWAYS** be used.



Be safe at all times!

Make sure this Ground Safety Recommendation is well exposed on your workplace (Safety Corner)